

SupaWarm



3000 Watt

Fan Heater

This manual is to be used with the following SupaWarm heater: **SFH3000**

IMPORTANT: Read these instructions before use. Please retain for future reference.

INSTRUCTION MANUAL




This product is only suitable for well insulated spaces or occasional use.



PARTS IDENTIFICATION

- (A) Air Intake
- (B) Adjustable Thermostat Dial
- (C) On / Off / Fan / Heat Switch
- (D) Power Indicator Light
- (E) Air Outlet



ATTENTION! This appliance is designed for domestic use only. DO NOT use for industrial purposes.

Images are for visual purposes only, actual product may differ from the image shown.

ELECTRICAL SAFETY

RATING

- 220-240V ~ 50Hz, 2750-3000W
- Ensure that the voltage indicated on the identification plate corresponds with the mains voltage.
- Weight: 1.6kg
- Class II

For your own safety, please read these instructions fully before use and retain for future reference.

DO NOT MOVE OR TURN HEATER UPSIDE-DOWN DURING OPERATION.

DISPOSAL

IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH EC DIRECTIVE 2012/19/EU.

At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service. Disposing of a household appliance separately avoids possible negative consequences for the environment and health, avoiding inappropriate disposal enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.



IMPORTANT SAFETY INSTRUCTIONS

**⚠ FOR YOUR OWN SAFETY!
PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE
USING THE PRODUCT.**

RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

Use the appliance only for the mentioned purpose, namely as a heater for domestic use. **DO NOT** use for any other application as this could be dangerous. The manufacturer is not responsible for any eventual damages caused by improper or faulty use.

The product is for household use only.

When using any electrically powered product, basic safety precautions should always be followed, as outlined in this instruction booklet.

⚠ WARNING! To reduce the risk of fire, electrical shock or injury to persons or property:

1. Before plugging your unit into the mains power supply, visually check that the unit is intact and has not suffered any transit damage.
2. Ensure the appliance is situated in an open area. Do not allow it to come into contact with cupboards, curtains, wall coverings, clothing or other flammable materials.
3. **DO NOT** install the appliance directly below an electrical socket.
4. **DO NOT** use this heater with a programmer, timer, separate remote-control system or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
5. **DO NOT** use this heater with an extension cable.
6. Check that the voltage indicated on the data plate corresponds with that of the local network before connecting the appliance to the mains power supply.

IMPORTANT SAFETY INSTRUCTIONS

7. Close supervision is required when using this appliance near children.
8. Never leave this appliance within reach of children.
9. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
10. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
11. Children of less than 3 years should be kept away unless continuously supervised.
12. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
13. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
14. **CAUTION!** Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
15. **DO NOT** use this fan heater in the immediate surroundings of a bath, shower or a swimming pool.
16. **DO NOT** use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.
17. **DO NOT** immerse the appliance or its cord in water or any other liquids.
18. **DO NOT** leave the appliance unattended during use.

IMPORTANT SAFETY INSTRUCTIONS

19. **DO NOT** leave the appliance unattended whilst connected to the mains supply.
20. Always use this appliance on a solid, level, non-flammable surface.
21. **DO NOT** use this appliance outdoors.
22. It is imperative to unplug the power cord after the appliance has been used, before it is cleaned and whilst being repaired.
23. Repairs to electrical appliances should only be performed by qualified personnel. Improper repairs may place the user at serious risk.
24. **DO NOT** operate this appliance with a damaged plug or cord, after a malfunction or after being dropped or damaged in any way.
25. Regular, periodic checks should be carried out on the mains cable to ensure no damage is evident. Should there be any signs of damage the appliance should not be used.
26. If the power cable is damaged, it should only be replaced by suitable qualified personnel in order to avoid a hazard
27. **DO NOT** allow the mains cable to hang over sharp edges or come into contact with hot surfaces.
28. **DO NOT** run the mains cable under carpets, rugs, etc.
29. Allow the unit to cool before storing.
30. Before cleaning, disconnect the appliance from the mains supply and allow to cool.
31. Never place the appliance near to flammable material or high pressure containers (e.g. paper, wood, petrol, solvents, spray canisters etc.)
32. This appliance is intended for household use only and should not be used for industrial purposes.
33. **DO NOT** use any accessories or attachments with this appliance other than those supplied or recommended by the manufacturer.

IMPORTANT SAFETY INSTRUCTIONS

34. **DO NOT** use this appliance for anything other than its intended use.
35. **DO NOT** push objects into any openings as damage to the appliance and/or electric shock may occur.
36. The appliance should not be installed in areas which have a fire-risk, such as garages, stables or wooden sheds; this is applicable also for rooms in which highly inflammable gasses or dust can develop. **Danger of fire!**
37. Unplug after each use. Grasp the plug, not the cord.
38. Should the fuse within the plug need replacing, you must use an ASTA approved one (conforming to BS 1362 of the same rating). If in doubt, consult a qualified electrician. Never use a plug with the fuse cover missing.



NEVER COVER THE HEATER!

WARNING! In order to avoid overheating, do not cover the heater.

⚠ CAUTION! Keep rugs and other soft furnishings away from the front of the heater. They could obstruct the free flow of air from the fan and damage both soft furnishings and the heater.

The heater must stand on a solid, level, non-flammable surface such as stone, slate, ceramic or concrete. **DO NOT** stand the heater on a carpet, rug or other soft floor covering.

This appliance has been ERP classified as a portable space heater and should only be used for supplementary, secondary or temporary heating. It should not be considered for primary permanent heating in a room or dwelling.

USING YOUR HEATER

Read and familiarise yourself with all operating instructions before using this fan heater.

Before the first time you use your fan heater, remove all packing materials and discard responsibly.

Operating instructions

- Place the fan heater on a solid, level non-flammable surface.
- Ensure that the **On / Off / Fan / Heat Switch** is in the **OFF** position.
- Check that the unit, power cord and plug aren't damaged.
- Make sure the power supply used corresponds to the one on the rating label.
- Insert the plug into the mains socket.

Heating mode

- For the low heat setting, rotate the **On / Off / Fan / Heat Switch** to the low heat position **I**.
- For the high heat setting, rotate the **On / Off / Fan / Heat Switch** to the high heat position **II**.
- Rotate the **Thermostat Dial** clockwise to increase the room temperature and anti-clockwise to decrease the room temperature as desired.

Please note:

- **The power light will illuminate on and off to indicate that the set temperature is being maintained, this is normal.**
- **During the first few minutes of initial use, you may notice a slight odour and a little smoke. This is normal and will quickly disappear. This is the coating applied to the heating elements to prevent any corrosion during transit.**

Tips on setting the correct temperature

- Select the desired heat range as described on page 8.
- Rotate the **Thermostat Dial** to the maximum position and allow the room to warm up. Once the desired room temperature has been reached, turn the **Thermostat Dial** anti-clockwise until the fan heater just clicks off, then turn it back up clockwise very slightly. The **Thermostat Dial** will now maintain the room temperature. If necessary, further increasing or decreasing of the **Thermostat** may be required to 'fine tune' the ideal room temperature.
- Return the **On / Off / Fan / Heat Switch** to the **O** position to switch off the fan heater.

Fan only mode

- For using the fan only, rotate the **On / Off / Fan / Heat Switch** to the  position.
- The **Thermostat** will need to be rotated to the fully clockwise position for the fan to operate.

CLEANING & MAINTENANCE

Always disconnect the heater from the mains power supply and allow to cool before cleaning.

- Clean the outside of the heater with a clean damp cloth. Never clean with harsh or abrasive chemicals and cleaners.
- Clean the air inlet and outlet regularly with a vacuum cleaner.
- Cleaning and user maintenance shall not be made by children without supervision.
- If the appliance is not used for extended periods, it must be protected against excessive dust and dirt.

WARNING

NEVER IMMERSE THE APPLIANCE INTO WATER OR ANY OTHER LIQUID!

- Do not allow the interior to get wet as this could create a hazard.
- Do not use any flammable cleaning agents e.g. petrol or spirit for cleaning the appliance.
- In case of malfunction or doubt, do not try to repair the heater yourself, it may result in a fire hazard or electric shock.

For long periods of non-use, store the heater in a dry, cool place. Preferably in its original packaging.

SAFETY CUT-OUT

WARNING! This appliance is fitted with a built-in safety cut-out, if the cut-out is activated the unit stops working, unplug the heater from the mains and check that the air intake area is not blocked or covered. Leave for an hour to cool and reset before plugging back into the mains.

DISPOSAL

Correct disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the UK/EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact your local government for information regarding the collection systems available.

If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

THANK YOU FOR PURCHASING

For a complete range of fires, radiators and heaters please call or visit Supa Brands for further information:

SupaWarm

Website: www.supabrands.co.uk

Helpline: **01473 237 997**

Part of the extensive Supa Brand Range

PO Box 1042, Ipswich, IP1 9XY

DECLARATION OF CONFORMITY



MUNRO IMPORTERS LTD

Declaration of Conformance
In accordance with UK Government Guidance



We, the importer:

Munro Importers Ltd
First Floor, Unit 1 The Quadrangle, The Drift, Nacton Road,
Ipswich, Suffolk, IP3 9OR

Declare that the product:
Product code: SFH3000 - 106781
Product description: Supawarm 3000W Fan Heater

Is in conformity with the relevant Statutory Instruments, Directives, and their amendments:

EMC Directive 2014/30/EU and The Electromagnetic Compatibility Regulations 2016.
Low Voltage Directive 2014/35/EU and The Electrical Equipment (Safety) Regulations 2016.
Commission Regulation (EU) 2015/1188 implementing Directive 2009/125/EC of the European Parliament and of the Council with regard to eco-design requirements for local space heaters.
Directive 2011/65/EU on the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (RoHS) with its Amendments (EU) 2015/863.

And is manufactured in accordance with the following Standard or standardized documents:
EN 62233:2008, EN 60335-2-30:2009+A11+A1+A12, EN 60335-1:2012+A11+A13+A1+A14+A2+A15,
BS EN 60335-1:2012+A15, BS EN 60335-2-30:2009+A12, BS EN 62233:2008,
EN IEC 55014-1:2021, EN IEC 55014-2:2021, EN IEC 61000-3-2:2019+A1:2021, EN 61000-3-3:2013+A1:2019,
BS EN 55014-1:2017 +A11:2020, BS EN 55014-2:2015, BS EN IEC 61000-3-2:2019, BS EN 61000-3-3:2013+A1:2019,
(EU) 2015/1188
EN 62321-1:2013, EN 62321-2:2014, EN 62321-3-1:2014, EN 62321-4:2014 +A1:2017, EN 62321-5:2014,
EN 62321-7-1:2015, EN62321-7-2:2017, EN 62321-6:2015, EN62321-8:2017

All documentation is held on file and is available, on request from:

Company:	Munro Importers Ltd
Country:	United Kingdom
Name:	Simon Sutton
Email Address:	Simon@munroimporters.co.uk
Position in Company:	Product Coordinator

Signature: 
Date of Issue (dd/mm/yyyy): 27/03/2024



This appliance is marked according to the UK Statutory Instrument 2013 No. 3113 on Waste Electrical and Electronic Equipment (WEEE) Regulations

By ensuring this product is disposed correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The symbol on the product indicates that this product may not be treated as household waste. Instead, it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. Disposal must be carried out in accordance with local environmental regulations for waste disposal.

For more detailed information about treatment, recovery, and recycling of this product, please contact your local city office, your household waste disposal service, or the shop where you purchased the product.

TECHNICAL DETAILS

Model No: SFH3000

Table: Model Identifier for Electric Local Space Heaters

Item	Symbol	Value	Unit
Heat Output			
Nominal heat output	P_{nom}	3.0	kW
Minimum heat output (indicative)	P_{min}	1.5	kW
Maximum continuous heat output	$P_{max, c}$	3.0	kW
Auxiliary Electricity Consumption			
At nominal heat output	e_{lmax}	0.012 (fan motor)	kW
At minimum heat output	e_{lmin}	0.012 (fan motor)	kW
In standby mode	e_{lsb}	0.0	kW
Type of heat input, for electric storage local space heaters only (single select)			
Manual heat charge control, with integrated thermostat			N/A
Manual heat charge control, with room and/or outdoor temperature feedback			N/A
Electronic heat charge control with room and/or outdoor temperature feedback			N/A
Fan assisted heat output			N/A
Type of heat output/room temperature control (single select)			
Single stage heat output and no room temperature control			<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
Two or more manual stages, no room temperature control			<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
With mechanic thermostat room temperature control			<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
With electronic room temperature control			<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
Electronic room temperature control plus day timer			<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
Electronic room temperature control plus week timer			<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
Other control options (multiple selections possible)			
Room temperature control, with presence detection			<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
Room temperature control, with open window detection			<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
With distance control option			<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
With adaptive start control			<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
With working time limitation			<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
With black bulb sensor			<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
Contact Details	PO Box 1042, Ipswich, IP1 9XY		

SupaWarm

**For a complete range of fires,
radiators and heaters**

please call or visit Supa Brands for further information:



www.supabrands.co.uk

01473 237 997

Part of the extensive Supa Brand Range

PO Box 1042, Ipswich, IP1 9XY
